


Installation Instructions Techmat Supply

FF109-200 1 Hour Fire Rated Light Cover

- Install junction box according to manufacturer instructions.
- Ensure metal wire included with your cover is going through the pre-punched through slots near the top of the cover so that the coil is secured around the outside of the cone.
- Step 、 Grasp the legs of the bronze wire firmly and roll cover into a tight cylinder.
 - Keeping a tight grip on the legs, feed the cover through the ceiling cutout.

Step

- Ensure cover has sprung back into its original cone shape before proceeding.
- Grasp legs and pull down until L section clears the underside of the ceiling.
- Move legs out until vertical part of L section is flush with the side of the cut out. tep
 - Release the legs so they grip the underside of the ceiling.
 - Remove the excess of both legs.



Ensure the cover fits your chosen light fixture.	WARNING: BE SURE THE ELECTRICITY TO THE SYSTEM YOU ARE WORKING ON IS TURNED OFF; EITHER THE FUSE REMOVED OR THE CIRCUIT BREAKER SET AT OFF.
 FF109-200 Overall Dimensions: Outside Diameter 7 7/8" Outside Height 8 1/4" 	 CONTAINS STONE WOOL INSULATION Stone fibers may cause temporary mechanical irritation to the skin, throat, nose and eyes. FIRST AID Skin If irritation occurs, do not rub or scratch. Rinse under running water prior to washing with mild soap and water. Consult a physician if irritation persists. Throat and Eyes If irritation occurs, flush eyes with water and/or drink water to clear throat. Do not rub the eyes. Consult a physician if irritation persists. PRECAUTIONS Wear long sleeve, loose fitting clothing, gloves and eye protection. For additional information, refer to the Material Safety Data Sheet (MSDS).





